



WINDOW FILM CLEANING INSTRUCTIONS

- Regular solar and decorative films will take up to 30 days to dry completely. V-Kool, Security, and Specialty Decorative films take 60-100 days to dry completely, especially solar control tinted security films. It is normal for film to appear hazy or milky with small bubbles during the drying time. Once film is completely dry the haziness and bubbles will disappear.
- Interior Installations without direct sunlight take longer to dry.
- Wait at least 30 days after installation for initial cleaning.
- Use NO abrasive cleaners on window film. Film has durable scratch resistant coating to withstand normal use.
- Recommend cleaning with soft cloth and regular window cleaning squeegees.
- Most effective cleaning agent is a combination of mild solution of dish detergent and water. Any non-abrasive, non-ammonia based retail cleaning products can be used safely and effectively.
- Following these basic instructions will ensure the longevity and optical clarity of your window film.